

# Diffusion and Poly-Si Line Resistance Tests

## Important Details

- Use 4-point probing for measurement of R
- Inner line segment is 20 squares ( $L = 200 \mu\text{m}$ ,  $W = 10 \mu\text{m}$ )

